Powerdot MICRO

935-PM31S

935-PM31W











hooks, are visible then it will not come off.


Note that it is extremely difficult to remove the cover once attached without harming the product.




INSERT Insert the Powerdot MICRO into the hole, then feed the power plug through the plastic fastening nut.









RE-ALIGN USB PORTS Plug the USB cable to each port to align the USB ports. Repeat for both USB ports.

